

JAM Session 3 – Clean and Sterile Storage

Clean and sterile supply storage protects our patients, supports safe care, and ensures regulatory compliance. Maintaining correct temperature, humidity, shelf distance, and package integrity keeps us CMS-ready every day, not just during surveys. Today's JAM Session focuses on maintaining these standards EVERY shift.

Environmental Standards:

- Temp: 68–75°F
- Humidity: 30–60%
- Positive pressure required
- Doors remain closed

Shelving Requirements:

- 18 in below sprinklers
- 8 in above floor
- 2 in from walls
- No items under plumbing

Packaging Integrity:

- No tears or moisture
- Check sterility indicators
- Remove expired/damaged items

Handling & Transport:

- Use covered clean carts
- Perform hand hygiene
- Do not place supplies on floors

FIFO Stock Rotation:

- Older items in front
- Newer items behind

Access the short video here:



Scan for training video

<https://drive.google.com/file/d/1mk-Z9CdbeA1fhQBHMvqM0EVCmtRzj2rK/view?usp=sharing>

